

OPEN FIRST!!

Parts list for Master set # 3-18119

© 2005 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Energy Suspension recommends that you read over all the installation instructions and parts list before you start.

Transmission mount:

- 1 - 1036 mount
- 1 - 15.810 backing plate
- 2 - 15.348 (7/16" lockwasher)
- 4 - 15.342 (7/16" flat washer)
- 2 - 15.530 (7/16"-14 x 1" bolt)
- 1 - 17112 installation instructions

Front end control arm bushing set:

- 4 - 3001 upper control arm bushings
- 4 - 15.011 (13/16" O.D. x .675" I.D. x 1.562" sleeve)
- 4 - "E" shells
- 2 - 3006 lower control arm bushings (front pos.)
- 2 - 15.010 (3/4" O.D. x 1/2" I.D. x 2.4" sleeve)
- 2 - "A" shells
- 2 - 3008 lower control arm bushings (rear pos.)
- 2 - 15.010 (3/4" O.D. x 1/2" I.D. x 2.4" sleeve)
- 2 - "B" shells
- 1 - 17444 installation instructions

Rear leaf spring and shackle bushing set (for mono-leaf):

- 4 - 2014 spring bushings (main eye)
- 2 - 15.001 (3/4" O.D. x 1/2" I.D. x 3.700" sleeve)
- 8 - 2017 bushings (shackle end)
- 1 - 17040 installation instructions

Rear leaf spring pad set:

- 2 - 6062 leaf spring pad upper
- 2 - 6063 leaf spring pad bushing lower
- 2 - 15.142 (5/8" O.D. x 1/2" I.D. x .470")

Front balljoint boot set:

- 2 - 13009 balljoint boots
- 2 - 13010 balljoint boots

Body mount set:

- 2 - 4001 bushings (bottom, position #1)
- 2 - 4002 bushings (top, position #1)
- 2 - 4003 bushings (top, position #3)
- 4 - 4004 bushings (bottom, position #2 & #3)
- 2 - 4005 bushings (top, position #2)
- 1 - 17013 installation instructions

Tie rod boot set:

- 4 - 13001 tie rod boots

Grease:

- 2 - 9.11101 grease tubs

Front sway bar endlink set:

- 8 - 4806 endlink grommets
- 8 - 15.301 cupped washers
- 2 - 15.021 (9/16" O.D. x 3/8" I.D. x 2.6" sleeve)
- 2 - 15.504 (3/8"-16 x 7" bolt)
- 2 - 15.701 (3/8"-16 nut)

17220
3/31/05 KN/NJT

ENERGY SUSPENSION®

1131 VIA CALLEJON, SAN CLEMENTE, CA

Additional parts available for your vehicle:

Body mount hardware set only:

(includes bolts, sleeves, and washers)

67-81 Camaro and Firebird Set # 3-4143

Front swaybar frame bushing sets:

UNIVERSAL/MULTI. APP. SWAY BAR BUSHING SET NUMBERS

Greasable Set #	Sway Bar Diameter	Non-Greasable Set #
9-5154	5/8" (16mm)	9-5104
9-5155	11/16"	9-5105
9-5156	3/4" (19mm)	9-5106
9-5157	13/16"	9-5107
9-5158	7/8" (22mm)	9-5108
9-5159	23mm	9-5115
9-5160	15/16" (24mm)	9-5109
9-5161	1"	9-5110
9-5162	1 1/16"	9-5111
9-5163	28mm	9-5130
9-5164	1 1/8"	9-5112
9-5165	1 1/4"	9-5113
9-5166	32mm	9-5116
9-5167	1 5/16"	9-5114
9-5168	1 3/8"	9-5136

Complete rear swaybar bushing set:: One bolt clamp style

Bar dia.	set #
5/8"	3-5107
11/16"	3-5110
3/4"	3-5109
13/16"	3-5124
7/8"	3-5110
15/16"	3-5112
1"	3-5113

Two bolt clamp style

Bar dia.	set #
9/16"	3-5103
5/8"	3-5104
11/16"	3-5165
3/4"	3-5106
13/16"	3-5123
7/8"	3-5105

Heavy duty shackle set:

For mono-leaf springs (includes shackle bushings and hardware only) set # 3-2137

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, etc. please ask to see our catalog at your place of purchase.