

OPEN FIRST!!

Parts list for Master set # 4-18115 1997-98 Expedition 4WD



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

©2001 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and parts list **before you start.**

Front end control arm bushing set: 4.3145

- 2 - 3308 (lower rr. pos.) bushings.
- 4 - 15.10.330.39 (1"O.D. x .640"I.D. x 4.0" sleeve)
- 2 - 3309 (lower frt. Pos.) bushings
- 4 - 3310 upper control arm bushings
- 1 - 17019 installation instructions

Front track rod: 4.7121

- 4 - 2331 bushing
- 2 - 15.10.199.39 (13/16"O.D.x 5/8"I.D.x 1.75 sleeve)
- 1 - 17039 installation instructions

Front tie rod boots: 9.13101

- 2 - 13001 Tie rod boot

Rear end control arm bushing set: 4.3146

- 4 - 8140 bushings (lower pos.)
- 4 - 15.10.135.39 (7/8"O.D. x 9/16"I.D. x 2.39" sleeve)
- 4 - 8141 bushings (upper pos.)
- 4 - 15.10.83.39 (7/8"O.D. x 9/16"I.D. x 2.030" sleeve)
- 1 - 17019 installation instructions

Rear sway bar bushing set: 4.5146

- 2 - 5405 22mm sway bar bushings
- 8 - 4902 end link bushings
- 4 - 15.10.342.39 (11/16"O.D.x1/2"I.D.x1.250 sleeve)
- 4 - 15.03.36.39 (1 3/4" O.D.x1/2"I.D.x.187 washer)
- 2 - 15.05.48.39 (12mm x1.75 x65mm bolt)
- 2 - 15.07.16.40 (12mmx 1.75 Nylock nut)

Parts list continued:

Body mount set: 4.4111

Must reuse all factory hardware.

- 8 - 4152 bushings (pos.2,3,4,5,upper)
- 8 - 4153 bushings (pos.2,3,4,5,lower)
- 2 - 4150 bushings (pos.1upper)
- 2 - 4151 bushings (pos.1lower)
- 1 - 17268 installation instructions

Front sway bar bushing set: 4.5145

- 2 - 5463 33mm sway bar bushing
- 8 - 4806 end link bushing
- 2 - 15.05.05.39 (3/8"-16x 7 1/2" grd.5 bolt)
- 2 - 15.10.24.39 (9/16"O.D.x3/8"O.D.x3.375" sleeve)
- 8 - 15.03.01.39 (cupped washer)
- 2 - 15.07.01.40 (3/8"-16 nylock nut)
- 1 - 17039 installation instructions

Grease:

- 4 - 9.11101 grease tubs

Additional parts available for your vehicle:

Shock boots

fits most aftermarket shocks (sold in pairs)
set # 9-8130

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, etc. please ask to see our catalog at your place of purchase.

17289

3/MAY/01 BRH