

# OPEN FIRST!!

## Parts list for Master set # 8-18103



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

### Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and parts list **before you start**.

#### Front control arm bushing set:

**You must reuse all the factory metal parts.**

- 2 - 3125 bushings, front upper position
- 2 - 3126 bushings, rear upper position
- 4 - 3129 bushings, front and rear lower position
- 1 - 17019 installation instructions

#### Rear control arm bushing and track(panhard) bar bushing set:

- 16 - 3127 upper and lower control arm bushings
- 8 - 15.121 (7/8"O.D. x 5/8"I.D. x 2.562" sleeve)
- 2 - 7047 track bar bushings
- 1 - 15.080 (7/8"O.D. x 5/8"I.D. x 1.800" sleeve)
- 2 - 7048 track bar bushings
- 1 - 15.320 (2"O.D. x 5/8"I.D. washer)
- 1 - 15.322 (2"O.D. x 1.188"I.D. washer)
- 1 - 17039 installation instructions
- 1 - 17040 installation instructions

#### Front swaybar (24mm)frame bushing and endlink bushing set:

- 2 - 5115 (24mm) frame bushings
- 4 - 4806 endlink grommets
- 4 - 15.301(1-1/4" O.D. x .385 I.D. washers)
- use 17039 installation instructions

#### Rear swaybar (18mm)frame bushing and endlink bushing set:

- 2 - 5041 (18mm) frame bushings
- 4 - 4806 endlink grommets
- 4 - 15.301(1-1/4" O.D. x .385 I.D. washers)
- use 17039 installation instructions

#### Tie-rod boot set:

- 4 - 13001 tie-rod boots

#### Grease:

- 2 - 9.11101 grease tubs

### Additional parts available for

#### Shock boots

fits most aftermarket shocks (2 per set)  
set # 9-8130

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, etc. please ask to see catalog at your place of purchase.