

OPEN FIRST!!

Parts list for Master set # 7.18107 95-98 NISSAN 240SX / S14



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

17422
8/DEC/04 BRH

© 2004 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Front control arm bushing set: 7.3108

- 2 - 3311 bushing.
- 2 - 3312 bushing.
- 2 - 15.10.329.39 sleeve (.875" x .563" x 2.500").
- 2 - 9.11108 grease.
- 1 - 17423 installation instructions.

Front strut rod bushing set: 7.7105

- 2 - 7119 inner bushing.
- 4 - 7120 outer bushing.
- 2 - 15.10.325.39 sleeve(1.000" x .563" x 2.745").
- 4 - 9.11108 grease.
- 1 - 17432 installation instructions.

Front sway bar and end link bushing set: 7.5114

- 2 - 5011 sway bar bushing (27mm dia. bar)
- 2 - 15.08.01.39 bracket.
- 2 - 15.03.42.39 washer (1"O.D. x 7/16" I.D.).
- 2 - 15.03.75.39 spacer (1.5" sq. x .406" x .312").
- 2 - 15.05.45.39 bolt (10mm - 1.25 x 35mm Lg).
- 2 - 8072 end link bushing.
- 2 - 8159 end link bushing.
- 1 - 9.11108 grease.
- 1 - 17039 installation instructions.

Rear sway bar and end link bushing set: 7.5113

- 2 - 5040 sway bar bushing. (16mm dia. bar)
- 2 - 15.08.02.39 mini bracket.
- 4 - 8147 end link bushing.
- 4 - 8148 end link bushing.
- 1 - 9.11108 grease.
- 1 - 17039 installation instructions.

Tie-rod boot set: 9.13103

- 2 - 13003 tie-rod boot.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list continued:

Rear control arm bushing set: 7.3119

- 2 - 3450 toe link bushings.
- 4 - 3451 lower control arm bushings.
- 6 - 15.10.335.39 sleeve (.875" x .500" x 1.943").
- 10 - 8309 control arm bushings.
- 10 - 15.10.518.39 sleeve (.875" x .500" x 1.565").
- 4 - 9.11101 grease.
- 1 - 17421 installation instruction.

- 1 - 17276 sway bar tape measure.

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.