

# OPEN FIRST!!

## Parts list for Master set # 3.18105

### Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

#### GM 4 x 4 tranny mount set: 3.1106

- 2 - 1023 upper mount
- 2 - 1024 lower mount
- 2 - 15.10.188.39 (7/8"O.D. x 9/16"I.D. x 1.875" sleeve)
- 2 - 15.08.12.39 "U" bent bracket
- 2 - 15.03.35.39 (rectangle plates)

#### Front leaf spring bushing set(aftermarket): 3.2112

- 4 - 2008 frame shackle bushings
- 2 - 15.10.28.39 (5/8"O.D. x 7/16"I.D. x 3.500" sleeve)
- 4 - 2011 main eye bushings
- 2 - 15.10.09.39 (3/4"O.D. x 9/16"I.D. x 3.500" sleeve)
- 4 - 2043 leaf shackle bushings
- 2 - 15.10.28.39 (5/8"O.D. x 7/16"I.D. x 3.500" sleeve)
- use 17040 installation instructions

#### Rear leaf spring bushing set (O.E.M.): 3.2106

- 12 - 2004 spring bushings
- 6 - 15.10.08.39 (3/4"O.D. x 9/16"I.D. x 3.000 sleeve )
- 1 - 17040 installation instructions

#### Body (cab) mount set: 3.4103 (must reuse factory metal cups and hardware)

- 2 - 4008 bushing
- 2 - 4009 bushing
- 2 - 4010 bushing
- 2 - 4059 bushing
- 4 - 4011 bushing
- 6 - 15.03.05.39 (1/2" flat washer)
- 2 - 15.05.11.39 1/2" x 5" bolt
- 1 - 17011 installation instructions



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2010 Energy Suspension. All rights reserved.  
May not be reproduced, in any form, or by any means,  
without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

### Parts list continued:

#### Parts list continued:

#### Complete greasable front swaybar bushing set: 3.5179

- 2 - 5352 bushing (1-1/16" I.D.)
- 2 - 15.12.20.39 bushing bracket
- 4 - 15.03.23.39 washers
- 2 - 15.10.18.39 (1.00"O.D. x 3/4"I.D. x 1.75 sleeve)
- 4 - 4901 bushing
- 1 - 17039 installation instructions
- 1 - 17145 installation instructions

#### Swaybar bushings

- 2 - 5354 bushing (1-1/4" I.D.)

#### Tie-rod boot sets: 9.13119

- 4 - 13007 tie-rod boot set

#### Additional parts available:

#### Transfer case torque mounts

for 1973-75 vehicles only set # 3.1107

#### Shock boots

fits most aftermarket shocks (2 per set)  
set # 9.8130

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.

# 17184

10/OCT/11 BRH  
Rev.1 5/9/2013 KLB