

OPEN FIRST!!

Parts list for Master Set # 3-18107



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2012 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle. Wheel alignment is almost always disturbed when suspension components are removed or replaced. It is recommended that you have the alignment checked on your vehicle at a qualified alignment shop. Energy Suspension recommends that you read over all the installation instructions and check all P/N's and quantities in the parts list before you start. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list. Prior to installation, make sure that your car is in excellent mechanical condition and that there are no suspension or steering related problems. This part has been designed to work only with a car that is in good state of repair. No matter how carefully we design our parts, this is one area we have no control over and cannot be held responsible.

Transmission mount: 3.1108

- 1 - 1036 mount
- 1 - 15.810 backing plate
- 2 - 15.348 (7/16" lockwasher)
- 4 - 15.342 (7/16" flat washer)
- 2 - 15.530 (7/16"-14 x 1" bolt)
- 1 - 17112 installation instructions

Front control arm bushing set: 3.3147

Must reuse all factory hardware

- 4 - 3092 upper control arm bushings
- 2 - 3134 lower control arm front positions
- 2 - 15.130 (7/8" O.D. x 5/8" I.D. x 3.562 sleeve)
- 2 - 3135 lower control arm rear positions
- 2 - 15.034 (7/8" O.D. x 5/8" I.D. x 3.00 sleeve)
- 1 - 17019 installation instructions

Rear leaf spring and shackle bushing set: 3.2128

- 8 - 2101 leaf spring bushings
- 4 - 15.008 (3/4" O.D. x 9/16" I.D. x 3.00" sleeve)
- 4 - 2102 rear frame shackle bushings
- 2 - 15.008 (3/4" O.D. x 9/16" I.D. x 3.00" sleeve)
- 1 - 17040 installation instructions

Body mount set: 3.4123

Must reuse all factory hardware.

Std. cab use the following.

- 4 - 4076 bushing (top)position #1 & #2
- 2 - 4077 bushing (top)pos. #4(rear-most loc.)
- 2 - 4078 bushing (bottom)pos. #1
- 4 - 4079 bushing (bottom)pos. #2 & #4(rear-most loc.)
- 1 - 17037 installation instructions

Extended cab models use the following bushings in addition to the bushings above.

- 2 - 4076 bushing (top)position #3
 - 2 - 4079 bushing (bottom)position #3
- use 17037 installation instructions

Tie-rod dust boot set: 9.13101

- 4 - 13001 tie-rod dust boots

Complete greaseable front swaybar bushing and endlink set: 3.5178 (1-1/4" diameter bar)

- 2 - 5354 (1-1/4" greaseable bushing)
- 2 - 15.12.20.39 (greasable bushing bracket)
- 4 - 15.323 (.702" O.D. x .402" I.D. flat washer)
- 8 - 4806 endlink grommets
- 8 - 15.301 (cupped washer)
- 2 - 15.504 (3/8"-16 x 7" bolt)
- 2 - 15.701 (3/8"-16 nut)
- 2 - 15.021 (9/16" O.D. x 3/8" I.D. x 2.6" sleeve)
- 1 - 17145 installation instructions

Ball-joint dust boot set: 9.13126

- 2 - 13013 ball-joint dust boots
- 2 - 13014 ball-joint dust boots

17193

9/NOV/15 BRH

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Pre-lube etc. Please ask to see our catalog at your place of purchase.