

# OPEN FIRST!!

## Parts list for Master set # 3-18112



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2014 Energy Suspension. All rights reserved.  
May not be reproduced, in any form, or by any means,  
without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle. Wheel alignment is almost always disturbed when suspension components are removed or replaced. It is recommended that you have the alignment checked on your vehicle at a qualified alignment shop. Energy Suspension recommends that you read over all the installation instructions and check all P/N's and quantities in the parts list before you start. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list. Prior to installation, make sure that your vehicle is in excellent mechanical condition and that there are no suspension or steering related problems. This part has been designed to work only with a vehicle that is in good state of repair. No matter how carefully we design our parts, this is one area we have no control over and cannot be held responsible.

### Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

#### Transmission mount: 3.1108

- 1 - 1036 mount
- 1 - 15.08.10.39 backing plate
- 2 - 15.03.48.39 (7/16" lockwasher)
- 4 - 15.03.42.39 (7/16" flat washer)
- 2 - 15.05.30.39 (7/16"-14 x 1" bolt)
- 1 - 17112 installation instructions.

#### Front end control arm bushing set: 3.3101

- 4 - 3001 upper control arm bushings
- 4 - 15.10.11.39 (.813"O.D.x.675"l.D.x1.562"sleeve)
- 4 - 15.02.05.39("E" shells)
- 2 - 3006 lower control arm bushings (front pos.)
- 2 - 15.10.10.39 (.750"O.D. x .500"l.D. x 2.4" sleeve)
- 2 - 15.02.01.39("A" shells)
- 2 - 3008 lower control arm bushings (rear pos.)
- 2 - 15.10.10.39 (.750"O.D. x .500"l.D. X 2.4" sleeve)
- 2 - 15.02.02.39("B" shells)
- \*\*\*2 - 15.02.27.39 oval shells
- \*\*\*2 - 15.10.10.39 (.750"O.D. x .500"l.D. X 2.4" sleeve)
- \*\*\*2 - 3032 oval bushings.
- 2 - 9.11108 grease tubes.
- 1 - 17444 installation instructions.

#### Rear control arm bushing set: 3.3132

- 8 - 3021 control arm bushings.
- 8 - 15.10.1039 (3/4"O.D. x 1/2"l.D. x 2.425" sleeve)
- 8 - 15.02.09.39 "I" shells.
- 6 - 3087 thrust washers.
- 6 - 3088 thrust washers.
- 2 - 3089 thrust washers.
- 1 - 9.11101 grease tubes.
- 1 - 17041 installation instructions.
- 1 - 17019 installation instructions.

#### Ball-joint dust boot set: 9.13125

- 2 - 13009 ball-joint boots.
- 2 - 13010 ball-joint boots.

\*\*\* These parts will be used on vehicles equipped with oval shells and bushings in the lower control arm(rear position) from the factory.Bushing # 3008 and 15.02.02.39 ("B" shell) will not be used on oval shell equipped vehicles.

### Parts list continued:

#### Front endlink set : 9.8118

- 8 - 4806 endlink grommets
- 8 - 15.03.01.39 (cupped washer)
- 2 - 15.05.04.39 (3/8"-16 x 7" bolt)
- 2 - 15.07.01.40 (3/8"-16 nut)
- 2 - 15.10.23.39 (9/16"O.D. x 3/8"l.D. x 2.9" sleeve)

#### Rear coil spring isolator set: 9.6118

- 2 - 6076 coil spring isolators.

#### Tie-rod dust boot set: 9.13101 (2 sets)

- 4 - 13001 tie-rod dust boots.

Additional parts available for your vehicle:

### UNIVERSAL/MULTI. APPLICATION SWAY BAR BUSHINGS

Greasable		Non-greasable	
Set #	Diameter	Set #	
9.5151	7/16"	9.5101	
9.5152	1/2"	9.5102	
9.5153	9/16"	9.5103	
9.5154	5/8" (16mm) --	9.5104	
9.5155	11/16"	9.5105	
9.5156	3/4" (19mm) --	9.5106	
9.5157	13/16"	9.5107	
9.5158	7/8" (22mm) --	9.5108	
9.5159	23mm	9.5115	
9.5160	15/16" (24mm)	9.5109	
9.5161	1"	9.5110	
9.5162	1 1/16"	9.5111	
9.5163	28mm	9.5130	
9.5164	1 1/8"	9.5112	
9.5165	1 1/4"	9.5113	
9.5166	32mm	9.5116	
9.5167	1 5/16"	9.5114	
9.5168	1 3/8"	9.5136	

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.

# 17218

2/OCT/14 BRH