

OPEN FIRST!!

ENERGY
SUSPENSION®

1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

Parts List for Master set # 5-18109

Parts list:

Energy Suspension recommends that you
read over all the installation instructions
and parts list **before you start.**

Front control arm bushing set: 5.3124

- 4 15.10.397.39 Sleeve (1.000x0.640x3.535)
- 4 3305 Lower control arm bushings
- 4 15.10.373.39 Sleeve (1.000x0.687x1.960)
- 4 15.02.19.39 "S" Shell
- 4 3034 Upper control arm bushings
- 1 17306 Instruction sheet
- 3 9.11101 Grease Tubs

Rear leaf spring bushing set: 5.2109/11

- 2 15.10.08.39 Sleeves (0.750x0.562x3.000)
- 4 15.10.276.39 Sleeves (0.875x0.562x3.000)
- 4 2176 Shackle eye bushings
- 8 2184 Main/rear eye bushings*
- 4 2185 Main eye bushings
- 1 17040 Instruction sheet
- 2 9.11101 Grease Tubs

Front sway bar bushings set: 5.5124/25

- 4 15.03.23.39 Washers (0.702x0.402x0.090)
- 2 15.08.16.39 Brackets
- 2 15.08.18.39 Grease fittings
- 2 15.08.19.01 Zerk cap
- 8 15.03.01.39 Washers (1.250"x0.385"x0.110")
- 2 15.05.07.39 Bolts (3/8-16 x 9")
- 2 15.07.01.40 Nuts (3/8 Nylock)
- 2 15.10.47.39 Sleeves (0.563"x0.397"x4.500")
- 8 8095 Endlink bushings
- 2 5351 30mm Sway bar bushings
- 2 5354 32mm Sway bar bushings
- 1 17145 Instruction sheet

* May not use all bushings

© 2005 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Body mount set: 5.4109

- 8 4148 Bottom body mount bushings
- 8 4149 Upper body mount bushings
- 1 17251 Instruction sheet

Tie rod boot set: 9.13131

- 2 13014 Tie rod boots

- * If you have 2.500" Main I.D. springs
 Use 4 #2176 for shackle position
 Use 4 #2184 for rear eye position
 Use 4 #2185 for main eye position
- * If you have 1.750" Main I.D. Springs
 Use 4 #2176 for shackle position
 Use 4 #2184 for rear eye position
 Use 4 #2184 for main eye position



101305 NT
17249.cdr
DODGE RAM