

OPEN FIRST!!

Parts list for Master set # 7-18101 1970-73 Datsun 240Z

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Front tension rod bushing set: 7-7102

- 4 - 7020 bushings
- 2 - 15.10.65.39 (.688"O.D. x .500"I.D. x 2.000" sleeve)

Front control arm bushing set: 7-3106

- 2 - 3060 bushings
- 2 - 15.10.55.39 (.750"O.D. x .562"I.D. x 2.450" sleeve)
- 2 - 3061 bushings
- 1 - 17019 installation instructions
- 2 - 9.11108 grease

Steering coupler set: 7-16101

- 1 - 16001 bushings
- 4 - 15.10.162.39 (.500"O.D. x .375"I.D. x .880"sleeve)
- 4 - 15.10.240.39 (.500"OD. X .313"I.D. X .875"sleeve)

Rack and pinion bushing set: 7-10101

- 1 - 10014.1(top drivers side)
- 1 - 10014.2(bottom drivers side)
- 1 - 10015.1(top passenger side)
- 1 - 10015.2(bottom passenger side)
- 1 - 17077 installation instructions

Rear control arm bushing set: 7-3104

- 8 - 3062 bushings (hub end)
- 4 - 15.10.201.39 (.750"O.D. x .650"I.D. x 1.830" sleeve)
- 4 - 3078 bushings (inner rear position)
- 2 - 15.10.49.39 (1.187"O.D. x 1.005"I.D. x 2.450" sleeve)
- 4 - 3077 bushings (inner front position)
- 2 - 15.10.95.39 (1.187"O.D. x 1.005"I.D. x 2.062"sleeve)
- 1 - 17019 installation instructions
- 2 - 9.11108 grease

Rear mustache bar bushing set: 7-1102

- Must reuse existing outer metal shell
- 4 - 1006 bushings
 - 2 - 15.10.67.39 (.875"O.D. x .625"I.D. x 2.600" sleeve)
 - 4 - 15.03.24.39 (2-1/2" O.D. x 5/8" I.D. washer)
 - 1 - 17064 installation instructions
 - 1 - 9.11108 grease

ENERGY SUSPENSION®

1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2005 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list continued:

Front end link set: 9-8120

- 8 - 4806 end link grommets
- 8 - 15.03.01.39 (cupped washers)
- 2 - 15.10.22.39 (.562"O.D. x .375"I.D. x 1.650" sleeve)
- 2 - 15.05.02.39 (3/8"-16 x 5-1/2" bolt)
- 2 - 15.07.01.39 (3/8"-16 nut)

Front and rear bump stop set: 7-6104

- 4 - 6016 bushings

Tie rod boots: 9-13103

- 2 - 13003 tie rod boots

Additional parts available for your vehicle:

Swaybar bushings

Front frame bushings	Bar dia.	Set #
	16mm	7-5112
	18mm	7-5101
	20mm	7-5102

Transmission crossmember mount bushing set: Set # 7-1101

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.

17200

22/JAN/14 BEL
REV. B ECN#14007