

OPEN FIRST!!

Parts list for Master set # 7.18107 95-98 NISSAN 240SX / S14



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

17422
5/APR/11 MAM

© 2011 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Front control arm bushing set: 7.3108

- 2 - 3311 bushing.
- 2 - 3312 bushing.
- 2 - 15.10.329.39 sleeve (.875" x .563" x 2.500").
- 2 - 9.11108 grease.
- 1 - 17423 installation instructions.

Front strut rod bushing set: 7.7105

- 2 - 7119 inner bushing.
- 4 - 7120 outer bushing.
- 2 - 15.10.325.39 sleeve(1.000" x .563" x 2.745").
- 4 - 9.11108 grease.
- 1 - 17432 installation instructions.

Front sway bar and end link bushing set: 7.5114

- 2 - 5011 sway bar bushing (27mm dia. bar)
- 2 - 15.08.01.39 bracket.
- 2 - 15.03.42.39 washer (1"O.D. x 7/16" I.D.).
- 2 - 15.03.75.39 spacer (1.5" sq. x .406" x .312").
- 2 - 15.05.45.39 bolt (10mm - 1.25 x 35mm Lg).
- 2 - 8072 end link bushing.
- 2 - 8159 end link bushing.
- 1 - 9.11108 grease.
- 1 - 17039 installation instructions.

Rear sway bar and end link bushing set: 7.5113

- 2 - 5040 sway bar bushing. (16mm dia. bar)
- 2 - 15.08.02.39 mini bracket.
- 4 - 8147 end link bushing.
- 4 - 8148 end link bushing.
- 1 - 9.11108 grease.
- 1 - 17039 installation instructions.

Tie-rod boot set: 9.13103

- 2 - 13003 tie-rod boot.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list continued:

Rear control arm bushing set: 7.3119

- 2 - 3450 toe link bushings.
- 4 - 3451 lower control arm bushings.
- 6 - 15.10.335.39 sleeve (.875" x .500" x 1.943").
- 10 - 8309 control arm bushings.
- 10 - 15.10.518.39 sleeve (.875" x .500" x 1.565").
- 4 - 9.11101 grease.
- 1 - 17421 installation instruction.
- 1 - 17276 sway bar tape measure.

Additional parts available for your vehicle:

Rear sub frame bushing set # 7.1117
Steering rack & pinion bushing set (with power steering only) # 7.10104

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.