

OPEN FIRST!!

Parts list for

© 2003 Energy Suspension. All rights reserved.
 May not be reproduced, in any form, or by any means,
 without the written consent of Energy Suspension.

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and parts list **before you start.**

Front end control arm bushing set:

- 4 - 2337 lower control arm bushing outer.
- 2 - 3307 lower control arm bushing center.
- 2 - 15.s324v lower control arm sleeve.
(7/8"O.D. x .500"l.D. x 2.140")
- 4 - 8164 upper control arm bushing.
- 4 - 15.s332v upper control arm sleeve.
(3/4"O.D. x 10mm"l.D. x 1.600")
- 1 - 17256 installation instructions.

Rear end control arm bushing set:

- 2 - 8144 lower trailing arm
- 2 - 15s374v lower trailing arm sleeve
(7/8"O.D. x 14mm"l.D. x 2.790")
- 6 - 8165 rear knuckle
- 6 - 15.155 rear knuckle sleeve
(3/4"O.D. x 12mm"l.D. x 1.760")
- 4 - 8167 upper control arm
- 4 - 15.s332v upper control arm sleeve
(3/4"O.D. x 10mm"l.D. x 1.600")
- 1 - 17274 installation instructions

Front and rear shock bushing set: (uppers only)

- 4 - 8163 upper position shock bushing.
- 4 - 8162 lower position shock bushing.

Parts list continued:

Manual transmission shifter bushing set:

- 4 - 1101 upper position shifter bushing
- 4 - 1102 lower position shifter bushing
- 1 - 17271 installation instructions

Grease:

- 3 - 9.11101 grease tubs.

Additional parts available for

Front anti-swaybar bushing set (does not include endlinks):

Bar Dia.	Set #
16mm	5-5133
18mm	5-5132
19mm	5-5130

Rear anti-swaybar bushing set (does not include endlinks):

Bar Dia.	Set #
12mm	5-5145
15mm	5-5146
18mm	5-5147

**Motor mount insert set:
 manual trans only
 (3 Torque mount positions only)**
 5-1103