

OPEN FIRST!!

Parts list for Master set # 16.18106 1992-96 Honda Prelude

ENERGY SUSPENSION®

1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2004 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Front end control arm bushing set: 16.3106

- 4 - 2294 lower control arm bushing outer.
- 2 - 3289 lower control arm bushing center.
- 2 - 15.10.224.39 lower control arm sleeve.
(3/4"O.D. x 12mm I.D. x 2.225")
- 8 - 2280 upper control arm bushing.
- 4 - 15.10.244.39 upper control arm sleeve.
(3/4"O.D. x 10mm I.D. x 1.577")
- 1 - 17152 installation instructions.

Front strut rod set: 16.7103

- 2 - 7096 rear position.
- 2 - 7097 front position.

Front shock bushing set: 16.8106

- 4 - 8096 upper shock bushing.
- 4 - 2295 lower shock bushing.
- 2 - 15.10.302.39 lower shock sleeve.
(3/4"O.D. x 12mm I.D. x 2.040")
- 1 - 17162 installation instructions.

Rear control arm bushing set: 16.3112

- 4 - 2355 lower control arm bushing.
- 2 - 15.10.83.39 lower control arm sleeve.
(7/8" O.D. X 9/16" I.D. X 2.030")
- 8 - 2280 upper control arm bushing.
- 4 - 15.10.244.39 upper control arm sleeve.
(3/4"O.D. x 10mm I.D. x 1.577")
- 1 - 17265 installation instructions.

17292

16/MAN/04 BRH
Updated 22/JAN/04 BRH
Updated 4/FEB/04 BRH

Parts list continued:

Rear shock bushing set: 16.8108

- 4 - 8196 upper shock bushing.
- 4 - 2356 lower shock bushing.
- 2 - 15.10.148.39 lower shock sleeve.
(3/4"O.D. x 12mm I.D. x 2.354")
- 1 - 17266 installation instructions.

Front and rear bump stops:

- 2 - 6134 front (uppers only) set # 16.9101
- 2 - 6144 rear (uppers only) set # 16.9102

Coil spring isolator set:

- 2 - 6133 front upper spring pad set: 16.6101
- 2 - 6143 rear upper spring pad set: 16.6103

Grease:

- 2 - 9.11101 grease tubs.

Additional parts available for your vehicle:

Rear trailing arm bushing set: # 16.7105

Motor mount insert set: # 16.1103 (manual trans only)

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.

B.O.M. For Master set # 16.18106

Updated 4/FEB/04 BRH
Updated 22/JAN/04
17/JUN/99 BRH
16-18106.cdr

Parts list:

Front end control arm bushing set:16.3106

- 4 - 2294
- 2 - 3289
- 2 - 15.10.224.39 sleeve.
(3/4"O.D. x 12mm I.D. x 2.225")
- 8 - 2280 upper
- 4 - 15.10.244.39 sleeve.
(3/4"O.D. x 10mm I.D. x 1.577")
- 1 - 17152 installation instructions.

Front strut rod set:16.7103

- 2 - 7096
- 2 - 7097

Front shock bushing set:16.8106

- 4 - 8096
- 4 - 2295
- 2 - 15.10.302.39 sleeve.
(3/4"O.D. x 12mm I.D. x 2.040")
- 1 - 17162 installation instructions.

Rear control arm bushing set: 16.3112

- 4 - 2355
- 2 - 15.10.83.39 sleeve.
(7/8" O.D. X 9/16" I.D. X 2.030")
- 8 - 2280
- 4 - 15.10.244.39 sleeve.
(3/4"O.D. x 10mm I.D. x 1.577")
- 1 - 17265 installation instructions.

Parts list continued:

Rear shock bushing set:16.8108

- 4 - 8196
- 4 - 2356
- 2 - 15.10.148.39 sleeve.
(3/4"O.D. x 12mm I.D. x 2.354")
- 1 - 17266 installation instructions.

Front and rear bump stops:

- 2 - 6134 set # 16.9101
- 2 - 6144 set # 16.9102

Coil spring isolator set:

- 2 - 6133 set: # 16.6101
- 2 - 6143 set: # 16.6103

Grease:

- 2 - 9.11101 grease tubs.

PARTS LIST:

- 1 - 17292

Packaging Instructions


All sleeves and instructions for
each set must be packaged
together in individual bags.

Fold the parts list # 17292 so the

"OPEN FIRST!!

On the Master set 16.18106"
Is clearly visible when packaged
on skin packing card.