# OPEN FIRST!!

## Parts list for
## Master set # 3.18110
### 78-88 Chevelle, Monte Carlo, El Camino

**Parts list:**
Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start.** Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

**Transmission mount set:: 3.1108**
1 - 1036 mount
1 - 15.08.10.39 backing plate
2 - 15.03.48.39 (7/16" lockwasher)
4 - 15.03.42.39 (7/16" flat washer)
2 - 15.05.30.39 (7/16"-14 x 1" bolt)
1 - 17112 installation instructions

**Front control arm bushing set: 3.3156**
2 - 15.02.02.39 ("B" shell)
2 - 3008 bushing (lower rear position)
2 - 15.10.10.39 sleeve (.750"O.D. x .500"I.D. x 2.400")
2 - 15.02.11.39 ("K" shell)
2 - 3217 bushing (lower front position)
2 - 15.10.45.39 sleeve(.750" O.D. x .500"I.D. x 3.000")
4 - 15.02.16.39 ("P" shell)
4 - 3083 bushing (upper control arm)
4 - 15.10.44.39 sleeve (.875"O.D. x .688"I.D. x 1.900")
1 - 17019 installation instructions

**Rear control arm bushing set: 3.3132**
8 - 15.02.09.39 ("I" shell)
8 - 3021 bushing
8 - 15.10.10.39 sleeve (.750"O.D. x .500"I.D. x 2.425")
6 - 3087 thrust washer
6 - 3088 thrust washer
2 - 3089 thrust washer
1 - 17019 installation instructions
1 - 17041 installation instructions

**Rear coil spring isolator set: 3.6108**
2 - 6138 isolator

**Front Swaybar endlink set: 9.8119**
8 - 4806 endlink grommets
2 - 15.10.24.39 sleeve (.563"O.D. x .375"I.D. x 3.375")
8 - 15.03.01.39 (cupped washer)
2 - 15.05.05.39 (3/8"-16 x 7-1/2" bolt)
2 - 15.07.01.40 (3/8"-16 nut)

17179

10/3/2013 KLB

ENERGY SUSPENSION®
1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2011 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means, without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

**Parts list** continued:

**Tie-rod boot set: 9.13101**
4 - 13001 tie-rod boots

**Ball-joint boot set: 9.13126**
2 - 13009
2 - 13010

## Additional parts available for your vehicle:

**UNIVERSAL/MULTI. APPLICATION SWAY BAR BUSHINGS**

| Greasable Set # | | Diameter | | Non-greasable Set # |
|---|---|---|---|---|
| 9.5151 | ----- | 7/16" | ----- | 9.5101 |
| 9.5152 | ----- | 1/2" | ----- | 9.5102 |
| 9.5153 | ----- | 9/16" | ----- | 9.5103 |
| 9.5154 | ----- | 5/8" (16mm) | -- | 9.5104 |
| 9.5155 | ----- | 11/16" | ----- | 9.5105 |
| 9.5156 | ----- | 3/4" (19mm) | -- | 9.5106 |
| 9.5157 | ----- | 13/16" | ----- | 9.5107 |
| 9.5158 | ----- | 7/8" (22mm) | -- | 9.5108 |
| 9.5159 | ----- | 23mm | ---- | 9.5115 |
| 9.5160 | ----- | 15/16" (24mm) | | 9.5109 |
| 9.5161 | ----- | 1" | ----- | 9.5110 |
| 9.5162 | ----- | 1 1/16" | ----- | 9.5111 |
| 9.5163 | ----- | 28mm | ----- | 9.5130 |
| 9.5164 | ----- | 1 1/8" | ----- | 9.5112 |
| 9.5165 | ----- | 1 1/4" | ----- | 9.5113 |
| 9.5166 | ----- | 32mm | ----- | 9.5116 |
| 9.5167 | ----- | 1 5/16" | ----- | 9.5114 |
| 9.5168 | ----- | 1 3/8" | ----- | 9.5136 |

**1978-88** Front Upper Bump Stop SET # 3.9102
**1978-85** Front Lower Bump Stop SET # 3.9150

**BODY MOUNT SET FOR**
**1978-88** MONTE CARLO SET # 3.4141

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.