OPEN FIRST!!

Parts list for Master set # 3.18124

1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2010 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means, without the written consent of Energy Suspension.

Parts list:
Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start.** Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Transmission mount Set: 3.1108
1 - 1036 mount
1 - 15.08.10.39 backing plate
2 - 15.03.48.39 (7/16" lockwasher)
4 - 15.03.42.39 (7/16" flat washer)
2 - 15.05.30.39 (7/16"-14 x 1" bolt)
1 - 17112 installation instructions

Front end control arm bushing set: 3.3147
4 - 3092 upper control arm bushings
(Uppers must reuse factory hardware)
2 - 3134 lower control arm bushings (front pos.)
2 - 15.10.130.39 (.875"O.D. x .625"I.D. x 3.562" sleeve)
2 - 3135 lower control arm bushings (rear pos.)
2 - 15.10.34.39 (.875"O.D. x .625"I.D. x 3.000" sleeve)
1 - 17019 installation instructions

Rear leaf spring and shackle bushing set: 3.2128
8 - 2101 spring bushings
4 - 2102 bushings (shackle end)
6 - 15.10.08.39 (.750"O.D. x .563"I.D. x 3.000" sleeve)
1 - 17040 installation instructions

Body mount set: 3.4146
Must reuse all factory hardware.
10 - 4076 bushings (top, all positions)
2 - 4078 bushings (bottom, position #1)
8 - 4079 bushings (bottom, positions #2-6)
1 - 17296 installation instructions.

Front ball joint boot set: 9.13126
2 - 13014 upper ball joint boots.
2 - 13013 lower ball joint boots.

Tie rod boot set: 9.13101
2 - 13001 tie rod boots.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list continued:

Front greaseable sway bar bushing and endlink set (32mm /1-1/4" bar): 3.5178
2 - 5354 bar bushings (1-1/4" bar diameter)
2 - 15.12.20.39 greaseable brackets.
8 - 4806 endlink grommets.
8 - 15.03.01.39 cupped washers.
2 - 15.10.21.39 (.562"O.D. x .375"I.D. x 2.6" sleeve)
2 - 15.05.04.39 (3/8"-16 x 7" bolt)
2 - 15.07.01.40 (3/8"-16 nut)
4 - 15.03.23.39 flat washer (.702"O.D. x .402"I.D.)
1 - 17145 installation instructions.

Additional parts available for your vehicle:

Complete greaseable rear swaybar bushing set: # 3.5205 (22mm)

Shock boots fits most aftermarket shocks (Sold in pairs) set: # 9.8130

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.