OPEN FIRST!!

Parts list for
Master set # 5.18102

72-85 ½ & ¾ ton Standard Cab Pickup 4WD

ENERGY SUSPENSION®
1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2008 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means, without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list:
Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start.** Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Front leaf spring bushing set: 5.2102
(1" eye only)
8 - 2029 spring bushings
4 - 15.10.29.39 (.625" O.D. x .500" I.D. x 2.850" sleeve)
1 - 17040 installation instructions

Rear leaf spring bushing set: 5.2102
(1" eye only)
8 - 2029 spring bushings
4 - 15.10.29.39 (.625" O.D. x .500" I.D. x 2.850" sleeve)
1 - 17040 installation instructions

Body (cab) mount set: 5.4101
2 - 4093 bushings (position #2, top)
2 - 4094 bushings (position #3, top)
4 - 4095 bushings (position #1, top and bottom) (.500" thk)
4 - 4096 bushings (position #2 & #3, bottom)
2 - 15.10.161.39 (.688" O.D. x .500" I.D. x 1.20" sleeve)
2 - 15.10.156.39 (.688" O.D. x .500" I.D. x 1.00" sleeve)
6 - 15.03.05.39 (2" O.D. x .500" I.D. washer)
4 - 15.03.28.39 (2.500" O.D. x .750" I.D. washer)
2 - 15.03.14.39 (2.500" O.D. x .500" I.D. washer)
1 - 17070 installation instructions

Tie-rod boot sets: 9.13101 (2 EA)
4 - 13001 tie-rod boot set

Additional parts available for your vehicle:

Transmission mount

1972-78 vehicles with 225ci set # 5-1101

Shock boots

fits most aftermarket shocks(sold in pairs)
set # 9-8130

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.

17215

14/MAR/11 BRH