OPEN FIRST!!

Parts list for Master set # 5.18104

1966-76 Chrysler A-Body

ENERGY SUSPENSION®
1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2010 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means, without the written consent of Energy Suspension.

Parts list:
Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start.** Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

5.3132- Front control arm bushing set: (Uppers only)
4 - 15.02.04.39 ("D" shell)
4 - 3203 upper control arm bushing
4 - 15.10.114.39 (.750"O.D. x .570"I.D. x 1.690" Sleeve)
4 - 15.03.32.39 embossed washer 1-3/8" O.D.
4 - 15.03.33.39 embossed washer 1-1/8" O.D.
1 - 17019 installation instructions
1 - 17043 installation instructions

5.7109- Front strut rod bushing set:
4 - 7011 strut rod bushing
2 - 15.10.201.39 (3/4"O.D. x 5/8"I.D. x 1-13/16" sleeve)

5.2105- Rear spring and shackle bushing:
8 - 2080 shackle bushing
4 - 2004 main eye bushing
1-1/2" main eye (uses 1/2" bolt)
2 - 15.10.45.39 (3/4"O.D. x 1/2"I.D. x 3.0" sleeve)
4 - 2024 main eye bushing
2" main eye (uses 5/8" bolt)
2 - 15.10.14.39 (7/8"O.D. x 5/8"I.D. x 3.125" sleeve)
1 - 17040 installation instructions

9.9119- Lower control arm bump stop set:
2 - 6032 bump stop
2 - 15.07.01.40 (3/8"-16 nut)

9.13101- Tie-rod boot cover set:
4 - 13001 tie-rod boot

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list continued:

9.8118- Front endlink bushing set:
8 - 4806 endlink grommet
8 - 15.03.01.39 (cupped washer)
2 - 15.07.01.40 (3/8"-16 nut)

For 1966-72 vehicles
2 - 15.10.23.39 (9/16"O.D. x 3/8"I.D. x 2.90" sleeve)
2 - 15.05.04.39 (3/8"-16 x 7" bolt)

For 1973-76 vehicles
2 - 15.10.22.39 (9/16"O.D. x 3/8"I.D. x 1.650" sleeve)
2 - 15.05.02.39 (3/8"-16 x 5-1/2" bolt)

Additional parts available for your vehicle:

Ball joint boot set: 5.13102

Transmission mount

1967-76 Dart/Demon	set # 5.1101
1973-76 Duster/Valiant	set # 5.1101
1970-74 Barracuda	set # 5.1101

SWAY BAR FRAME BUSHINGS

(1973-76 models only)

Diameter		Set #
13/16"	----	5.5112
7/8"	-----	5.5113
15/16"	-----	5.5115

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.