

INSTRUCTION SHEET FOR SET #3-4114


Read this instruction sheet thoroughly before initiating any work!





1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

NOTE: When disassembling the body mounts, be sure to note the number and position of shims that may have been used to align the body. These shims will have to be reused to retain proper body alignment.

CAUTION: Remove all the body mount bolts on one side of the vehicle. Loosen but do not remove all the body mount bolts on the opposite side of the vehicle. Only raise one side of the vehicle at a time, lifting the body only high enough to remove/replace the mounts. Always watch the fan shroud, brake lines, and various hoses for sufficient clearance when raising the body. When jacking the body, use a 2x4 or equivalent to spread the weight. Never place jack faces directly on body panels!



When all mounts and hardware are installed, torque all bolts to factory specifications.



Position #1

- 1. Factory Washer
- 2. 4045
- 3. Bracket
- 4. 4042
- 5. Factory Washer w/sleeve
- 6. Frame

Position #3, #6

- Free standing mount-4040
- No hardware used.

Position #2, #4, #5

- 1. Body
- 2. Factory Washer w/sleeve
- 3. 4042
- 4. Frame
- 5. 4045
- 6. Factory Washer

Position #7, #8

- 1. Body
- 2. Factory Washer w/sleeve
- 3. 4041
- 4. Frame
- 5. 4044
- 6. Factory Washer

Revised by NJT
5-8-02
17021
NJ

© 2002 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.